



# Assembly Guide


E4478 - E4479 - E4480 - E4481 - E4482

## Quattro Plus Midi




2015.09


First check the contents to make sure that nothing is missing. Sort out the screws and fittings as shown.  
Assemble your furniture step by step, as shown in the illustrations.




4 x E466010




2 x E422511



4 x E422514




2 x E422512




4 x E422510



4 x E422513



8 x E422412




2 x E409505



4 x E4123

**4425**




16 x E9050




16 x E9740



4 x E40418



4 x E40146



1 x E33232

